

BG7BA-G0B - GTW7C51B 735218

USP: Product Type

Button Shape Single-manual electric ignition of gas burners for hob

Wok burner

Secure gas burners

Cooking area

Ergonomic buttons

The single-hand ignition of the burner makes managing your gas cooker even more comfortable and simpler. To light the gas burner, simply press the button with one hand and turn it to the desired level, leaving your other hand completely free. Fast, easy and efficient.

Double wok burner

ProGrids' massive and elegant cast iron bars are extremely stable and resistant even to maximum temperatures. They enrich your kitchen with first-class stability, durability and user-friendly design.

Basic information : Type of apparatus Brand Commercial product code Product Code

EAN Code Type of construction Management method

Type of inlet energy Total number of cooking surfaces which can be used at the same time

Number of gas fuel ers Number of electric cooking points Number of electric hobs Number of radiant radiant heater Number of halogen radiant heats Number of induction heaters

Number of electrical heating surfaces Control panel location

Gas type

Basic material of the outer surface of the cooker Cooking color

Frame Type Cooking area edge material Power of the electrical connection Rated fuse current Voltage Frequency Signs of conformity

Type of plug Product Width Product Height Product depth

Height of wrapped product Depth of the wrapped product Minimum height of the installation opening Maximum height of the re-installation aperture Maximum width of the installation aperture

Installation hole depth Net mass Gross mass

Specifics: Brief product description

Automatic programs Position 1, heating element Type 1. Heating element Mere1. heating element Position 2. heating element Type 2. Heating element Dimensions 2. heating element

Power 2. Heating element

Burning 735218 3838782384097 Embedded Mechanical

Gas hob

On the side of the cooking G20/20 Natural gas Black

N/A N/A 0 W 0.0 A 220-240 V 50/60 Hz

CE006321,EAC,0.00,UATR01221

No plug, cord 3x0.75

750 mm 136 mm 520 mm 170 mm 605 mm 100 mm 0 mm 0 mm 490 mm 22.0 kg 23.0 kg

BG7BA-G0B - GTW7C51B Front Left Large burner 98.5 mm 3000/0,0/0,0 W Rear Left Normal burner 73.5 mm

1800/0,0/0,0 W

Glavno stikalo za vklop/izklop Vključena dodatna oprema Programska ura

Skica vgradnje :

Plinske šobe G30/G31-28-30/37 tekoči plin Ne